

**EXTRA POWER START & STOP EFB**

<b>CODICE</b>	<b>GRUPPO DIM.</b>	<b>AH</b>	<b>SPUNTO EN</b>	<b>POLARITÀ</b>	<b>DIMENSIONI (mm)</b>	<b>ATTACCHI BASE</b>
AE60640E	L02	60	640	D	242x175x190	B13
AE70720E	L03	70	720	D	278x175x190	B13
AE80720E	L04	80	720	D	315x175x190	B13

**TRUCK**

<b>CODICE</b>	<b>GRUPPO DIM.</b>	<b>AH</b>	<b>SPUNTO EN</b>	<b>POLARITÀ</b>	<b>DIMENSIONI (mm)</b>	<b>ATTACCHI BASE</b>
AE60680A	L02	60	680	D	242x175x190	B13
AE70760A	L03	70	760	D	278x175x190	B13
AE80800A	L04	80	800	D	315x175x190	B13
AE95850A	L05	95	850	D	353x175x190	B13
AE110750	D02	110	750	D	348x175x232	B0
AE120680	MAC	120	680	D	510x175x225	B3
AE120680X	A	120	680	S	510x189x215	B0
AE140800X	A	140	800	S	513x189x215	B0
AE140900	ATM	140	900	D	513x175x205	B0
AE155900	MAC	155	900	D	513x218x225	B3
AE155900X	B1	155	900	S	513x223x215	B0
AE1801000	B2	180	1000	D	513x223x225	B3
AE1801000X	B2	180	1000	S	513x223x215	B0
AE2101200X	C	210	1200	S	518x274x240	B0

**TRUCK SHD**

<b>CODICE</b>	<b>GRUPPO DIM.</b>	<b>AH</b>	<b>SPUNTO EN</b>	<b>POLARITÀ</b>	<b>DIMENSIONI (mm)</b>	<b>ATTACCHI BASE</b>
AE1801000XSHD	D05	180	1000	S	513x223x215	B0
AE2251100XSHD	D06	225	1100	S	518x274x241	B0

# ATTACCHI BASE

Attacco Base  
B0 CAR




Attacco Base  
B1 CAR




Attacco Base  
B7 CAR




Attacco Base  
B9 CAR



Attacco Base  
B13 CAR




Attacco Base  
B13+14 CAR




Attacco Base  
B0 TRUCK



Attacco Base  
B1 TRUCK



Attacco Base  
B3 TRUCK



Attacco Base  
B4 TRUCK

